ALCOVE HINGE SHOWER SERIES

INLINE - 2 PANELS

Dimension A

TOP VIEW

Dimension A

HP

(Hinge Panel)

The doo<mark>r</mark> is reversible

DP

(Door Panel)

869


20

N.

861

85

∕a



Before you install your project, please read this installation guide carefully, consider the gap between each part, calculate the exact length before cutting.

The corners and edges of toughened glass are its weakest points, so ensure they are well-protected during installation.

Always use rubber spacers to separate stainless steel hardware from the glass to avoid damage.

FF DF HEA a b c c d d e f f	
DF HEA a b c c d d e f f	Dimens
HI HEA a b c c d d e f f g	Dimens
DF HEA a b c c d d e f f	FF
HEA a b c d d e f g	DI
a b c d d e f g	HF
b c d e f g	HEA
c d e f g	а
d e f g	b
e f g	С
f g	d
g	е
	f
hf	g
111	hf
hf	hf
hf	hf
	L

For more detailed information, please contact the team: email sales@grandglass.co.nz ph 09 478 9778 or 027 755 7705 www.grandglass.co.nz



Grand Glass Hinge Shower Installation Guide Complies with NZS3604:2011

ADD: 18a Parkway Drive, Rosedale

Hinge Panel Height 1950 mm

Important:

After completing the installation, it is essential to clean both the glass and the hardware. Proper cleaning of the glass helps maintain its protective coating, and cleaning the hardware removes any metal debris from the installation process, preventing potential rust.

Additionally, regular cleaning afterward is recommended to ensure long-term durability and maintain optimal performance.


LEGEND				
sion A	The overall dimension including gaps between wall and all glass panels (±1mm to all gaps recommended).			
sion B	The overall depth including gaps between wall and return panel (±1mm to all gaps recommended).			
D	Flat Panel			
D	Door Panel			
D	Hinge Panel			
DF	Head Flat Panel			
	Wall, channel, rubber and glass panel fixing detail			
	Gap between door and hinge panel			
	Gap of door on handle side			
	Floor channel and wall channel joint			
!	Gap between door and floor			
	Gap between door and return panel			
	Flat panel 90° joint			
1	Head panel clamp layout 1			
2	Head panel clamp layout 2			
3	Head panel clamp layout 3			
	•			

Drawn By : SW	Date :	Paper Size :	A3
Checked By : JQ	1/22/2025	Scale :	NTS
Drawing No. : GGH-RS01		Rev. No. :	0
		Sht. No. :	1

RECTANGLE HINGE SHOWER SERIES

RECTANGLE - 3 PANELS

RECTANGLE - 4 PANELS





Grand Glass Hinge Shower Installation Guide


Complies with NZS3604:2011

ADD: 18a Parkway Drive, Rosedale.


PH: 09 478 9778 , 027 755 7705

	Drawn By: SW	Date :	Paper Size :	A3
	Checked By : JQ	1/22/2025	Scale :	NTS
Γ	Drawing No. : GGH-RS01		Rev. No. :	0
		301	Sht. No. :	2

FIXING DETAIL








FIXING DETAIL d

Drawn By : SW	Date :	Paper Size :	A3
Checked By : JQ	1/22/2025	Scale :	NTS
	Drawing No. : GGH-RS01		0
	301	Sht. No. :	3

FIXING DETAIL - HEAD PANEL



ADD: 18a Parkway Drive, Rosedale. PH: 09 478 9778 , 027 755 7705

Drawn By : SW	Date :	Paper Size :	A3
Checked By : JQ	1/22/2025	Scale :	NTS
	Drawing No. : GGH-ILS01		0
	L301	Sht. No. :	4